Solutions to Problems: Chapter 25 Problems appeared on the end of chapter 25 of the Textbook

(Problem 16, 30, 42, 44, 58, 60, 66, 72)

16. **Picture the Problem**: Radio signals travel from Earth to a distant spacecraft.

Strategy: Divide the distance by the speed of light to calculate the time for the signal to reach the craft.

Solution: Calculate the time: $\Delta t = \frac{d}{c} = \frac{4.5 \times 10^{12} \text{ m}}{3.00 \times 10^8 \text{ m/s}} = \boxed{1.5 \times 10^4 \text{ s}}$

Insight: This time delay is 4 hours and 10 minutes. When NASA sends a signal to the craft it takes 8 hours and 20 minutes for NASA to receive a confirmation from the satellite.

30. **Picture the Problem**: The radiation emitted by humans has a wavelength of about 9.0 μ m.

Strategy: Solve equation 25-4 to calculate the frequency. Then compare the frequencies to the ranges given in section 25-3 of the text.

Solution: 1. (a) Calculate the frequency: $f = \frac{c}{\lambda} = \frac{3.00 \times 10^8 \text{ m/s}}{9.0 \times 10^{-6} \text{ m}} = \boxed{3.3 \times 10^{13} \text{ Hz}}$

- **2.** (b) This frequency falls in the infrared range $(10^{12} \text{ Hz to } 4.3 \times 10^{14} \text{ Hz})$.
- 42. **Picture the Problem**: A sinusoidal electric field has a maximum value of 65 V/m.

Strategy: Divide the peak electric field by the square root of two to calculate the rms magnitude of the electric field.

Solution: Calculate the rms electric field: $E_{\text{rms}} = \frac{E_{\text{max}}}{\sqrt{2}} = \frac{65 \text{ V/m}}{\sqrt{2}} = \boxed{46 \text{ V/m}}$

Insight: The rms magnetic field for this wave is 1.5×10^{-7} T.

44. **Picture the Problem**: A given electromagnetic wave has a maximum intensity of 5.00 W/m².

Strategy: Solve equation 25-10 for the maximum electric field.

Solution: Calculate E_{max} : $I_{\text{max}} = c\varepsilon_0 E_{\text{max}}^2$ $E_{\text{max}} = \sqrt{\frac{I_{\text{max}}}{c\varepsilon_0}} = \sqrt{\frac{5.00 \text{ W/m}^2}{\left(3.00 \times 10^8 \text{ m/s}\right) \left(8.85 \times 10^{-12} \text{ C}^2 / \text{N} \cdot \text{m}^2\right)}} = \boxed{43.4 \text{ V/m}}$

Insight: Verify for yourself that the maximum magnetic field for this wave is $0.145 \mu T$.

58. **Picture the Problem**: A 75.0-W lightbulb emits electromagnetic waves uniformly in all directions.

Strategy: Use equation 14-7 to calculate the intensity of the light 3.5 m from the source. Insert the intensity into equation 25-10 to calculate the rms electric field, and then solve equation 25-9 for the magnetic field.

Solution: 1. Divide the power by $I_{av} = \frac{P_{av}}{A} = \frac{75 \text{ W}}{4\pi (3.50 \text{ m})^2} = 0.4872 \text{ W/m}^2$ area:

$$I_{\text{av}} = c\varepsilon_0 E_{\text{rms}}^2$$

$$E_{\text{rms}} = \sqrt{\frac{I_{\text{av}}}{c\varepsilon_0}} = \sqrt{\frac{0.4872 \text{ W/m}^2}{\left(3.00 \times 10^8 \text{ m/s}\right) \left(8.85 \times 10^{-12} \text{ C}^2 / \text{Nm}^2\right)}} = \boxed{13.5 \text{ V/m}}$$

$$B_{\text{rms}} = \frac{E_{\text{rms}}}{c} = \frac{13.55 \text{ V/m}}{3.00 \times 10^8 \text{ m/s}} = \boxed{45.2 \text{ nT}}$$

Insight: The magnetic field could also have been calculated using $I_{av} = \frac{c}{\mu_0} B_{rms}^2$ (equation 25-10).

60. **Picture the Problem**: A 2.8-mW laser beam has a diameter of 2.4 mm.

Strategy: Write the intensity as the average power divided by the area of the beam. Write the intensity in terms of the rms electric field using equation 25-10 and solve for the electric field.

Solution: 1. Write
$$I_{av}$$
 in terms of

$$E_{\rm rms}$$
:

$$I_{\rm av} = \frac{P_{\rm av}}{A} = c\varepsilon_0 E_{\rm rms}^2$$


$$\begin{split} E_{\rm rms} &= \sqrt{\frac{P_{\rm av}}{Ac\varepsilon_0}} \\ &= \sqrt{\frac{2.8 \times 10^{-3} \text{ W}}{\pi \left(1.2 \times 10^{-3} \text{ m}\right)^2 \left(3.00 \times 10^8 \text{ m/s}\right) \left(8.85 \times 10^{-12} \text{ C}^2/\text{N} \cdot \text{m}^2\right)}} \\ E_{\rm rms} &= \boxed{0.48 \text{ kV/m}} \end{split}$$

Insight: Note that the electric field is inversely proportional to the beam diameter. If the diameter is doubled to 4.8 mm, the electric field will drop to 240 V/m.

66. **Picture the Problem**: The image shows unpolarized light incident upon two polarizers. the transmission axes of which are oriented at some angle with respect to each other.

Strategy: Set the intensity after the first polarizer equal to half

the intensity before (equation 25-14). Use Malus' Law (equation 25-13) to calculate the intensity after the second polarizer. Divide the result by the initial intensity to determine the relative intensity.



polarizer:

$$I_1 = \frac{1}{2}I_0$$

intensity after the second polarizer:


$$I_2 = I_1 \cos^2 \theta = \frac{1}{2} I_0 \cos^2 \theta$$

$$\frac{I_2}{I_0} = \frac{1}{2}\cos^2 30.0^\circ = \boxed{0.375}$$

Insight: The exact orientation of the two polarizers is not important, only the relative orientation of their transmission axes.

72. **Picture the Problem**: The image shows unpolarized laser light passing through three polarizers.

Strategy: Use equation 25-14 to calculate the intensity after the first polarizer. Then use Malus's Law (equation 25-13) to calculate the intensity as the light passes through each of the other polarizers.



Solution: 1. (a) Use equation 25-14 to calculate *I* at point A:

$$I = \boxed{\frac{1}{2}I_0}$$

- **2. (b)** Use Malus's Law to calculate the intensity at point B:
- $I = \left(\frac{1}{2}I_0\right)\cos^2 30.0^\circ = \boxed{0.375I_0}$
- **3. (c)** Use Malus's Law to calculate the intensity at point C:
- $I = (0.375I_0)\cos^2(90.0^\circ 30.0^\circ) = \boxed{0.0938I_0}$
- **4. (d)** Use Malus's Law to calculate the intensity at point C, with the second polarizer removed:

$$I = \left(\frac{1}{2}I_0\right)\cos^2 90.0^\circ = \boxed{0}$$

Insight: The second filter rotates the polarization so that some light can pass through the third filter.